

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

Configuration and Operation manual



Kronback tracers S16

	Kronback ApS Lautrupvang 15 DK-2750 Ballerup Denmark Web: www.kronback.com Fax:(+45) 46 907 910		Page 1 of 33
--	--	--	--------------

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

CONTENT

1.	PHYSICAL CONNECTIONS	4
1.1.	Input connector and LED	5
1.2.	Output connector	6
1.3.	USB connector	7
1.4.	Console connector	8
1.4.1.	RS232 parameters	8
1.4.2.	Connector pinout	8
1.4.3.	Console cable pinout	8
1.5.	Status LEDs	9
1.5.1.	PSU LED	9
1.5.2.	TEMP LED	9
1.5.3.	FAULT LED	9
1.6.	Local button	10
1.7.	Network Connector	11
1.7.1.	PoE power supply	11
1.7.2.	LED indicators	11
2.	SPECIFICATIONS	12
2.1.	STANDARD COMPLIANCE	12
2.2.	NETWORK CABLE	12
2.3.	RF SPECIFICATIONS	12
2.4.	CONSOLE	13
2.5.	CERTIFICATION	13
2.6.	PHYSICAL SPECIFICATIONS	13
2.7.	ELECTRICAL	13
2.8.	ENVIRONMENTAL	13
3.	USER INTERFACE	14
3.1.	RF SWITCH menu	14
3.1.1.	Active Input	14
3.1.2.	Input Selection	14
3.1.3.	Submit input selection button	14


	Kronback ApS Lautrupvang 15 DK-2750 Ballerup Denmark Web: www.kronback.com Fax:(+45) 46 907 910		Page 2 of 33
--	--	--	--------------

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

3.2. INPUT menu	15
3.3. SUPPORT menu	16
3.4. CONTACT menu	16
3.5. SETUP menu	17
3.5.1. IP address	17
3.5.2. Port	17
3.5.3. Switch topology	18
3.5.4. Input steps	18
3.5.5. Topology example 61 inputs	19
3.5.6. State check	20
3.5.7. LED ´s on unused inputs	20
4. SP16T AND COMBINER MODE	21
4.1. SP16T mode	21
4.2. Combiner mode	21
5. NETWORK SETUP	22
5.1.1. Factory network settings	22
5.1.2. DHCP	22
5.1.3. Link speed	22
5.1.4. Network configuration.	22
6. CONSOLE INTERFACE	23
6.1.1. RS232 parameters	24
6.1.2. Console Cable	24
6.1.3. Using the console interface	25
6.1.4. Configuration menu	25
6.1.5. Command 1, Set IP address	26
6.1.6. Command 2, Set TCP port	27
6.1.7. Command 3, Factory Reset	28
6.1.8. Command 4, Exit	29
7. SOCKET COMMAND PROTOCOL	30
7.1. SET OUT	31
7.2. GET OUT	32
7.3. SET Combiner mode	33

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010


1. Physical connections



- 1 INPUT CONNECTOR AND LED
- 2 OUTPUT CONNECTOR
- 3 USB CONNECTOR
- 4 CONSOLE CONNECTOR
- 5 STATUS LED
- 6 ETHERNET CONNECTOR
- 7 LOCAL CONTROL BUTTON

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

1.1. Input connector and LED



The 16 F-type input connectors are mechanically fixed in the chassis front by a double D-cut hole.

The connectors can withstand torques > 4.5 Nm (40 lb*inch)

Over each connector is a red LED that indicates which of the 16 input connectors that are active.

All input connectors are DC blocked up to 10V

All F-connectors are high quality CABLECON type.

	Kronback ApS Lautrupvang 15 DK-2750 Ballerup Denmark Web: www.kronback.com Fax:(+45) 46 907 910		Page 5 of 33
--	--	--	--------------

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

1.2. Output connector



The F-type output connector is mechanically fixed in the chassis front by a double D-cut hole.

The connector can withstand torques > 4.5 Nm (40 lb*inch)

The output connector is DC blocked up to 10V

	Kronback ApS Lautrupvang 15 DK-2750 Ballerup Denmark Web: www.kronback.com Fax:(+45) 46 907 910		Page 6 of 33
--	--	--	--------------

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

1.3. USB connector



The USB type mini-B connector is used for control of the **S16**.

The protocol follows the HID standard (Human Interface Device), and requires no driver software installed on the connected PC.

A control program can be downloaded from www.kronback.com/s16usb.zip

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

1.4. Console connector



The console interface is used for configuring the basic IP parameters of the **S16**. The connector is a standard RJ45 type.

1.4.1. RS232 parameters

RS232 parameter	Value
Baud rate	9600 bps
Data bits	8
Parity	None
Stop bit	1
Flow control	None

1.4.2. Connector pinout

pin	function
1	NC
2	NC
3	S16 data TX
4	ground
5	ground
6	S16 data RX
7	Programming use, connect to ground
8	Programming use, connect to ground


1.4.3. Console cable pinout

S16 RJ45 pin	direction	PC RS232 dsub9 female	Function
3	→	2	S16 data TX
4		5	ground
5		5	ground
6	←	3	S16 data RX
7		5	ground
8		5	ground

	Kronback ApS Lautrupvang 15 DK-2750 Ballerup Denmark Web: www.kronback.com Fax:(+45) 46 907 910		Page 8 of 33
--	--	--	--------------

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

1.5. Status LEDs



3 Status LEDs are present on the **S16** front.

1.5.1. PSU LED

The PSU LED is directly connected to the internal power circuit. This LED must always be on.

1.5.2. TEMP LED

This LED lights if the internal temperature of **S16** exceeds +60 °C [140 °F].

1.5.3. FAULT LED

This indicates that the internal watch dog circuit is not being triggered. This indicates a CPU fault.

During power up this LED blinks 2-3 times


	Kronback ApS Lautrupvang 15 DK-2750 Ballerup Denmark Web: www.kronback.com Fax:(+45) 46 907 910		Page 9 of 33
--	--	--	--------------

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

1.6. Local button




The Local button is used for front panel operation. For each push the selected input increments by 1. After input 16 the All-on combiner mode is selected followed by all-off mode.



kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

1.7. Network Connector




The RJ45 Network connector is supporting 10 or 100 Mbit/s link speed, and half or full duplex.

MDIX is supported for both straight and crossed twisted-pair cables.

1.7.1. PoE power supply

S16 is powered via PoE (Power Over Ethernet) following the 802.3af standard and operates as a Class I device (max 4W).


Either a dedicated PoE power supply or a PoE enabled Ethernet switch should be used.



1.7.2. LED indicators

The top left LED (green) indicates that LINK is established

The top right LED (green) when lighting indicates activity



	Kronback ApS Lautrupvang 15 DK-2750 Ballerup Denmark Web: www.kronback.com Fax:(+45) 46 907 910		Page 11 of 33
--	--	--	---------------

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

2. Specifications

2.1. STANDARD COMPLIANCE

IEEE 802.3 10Base-T Ethernet
 IEEE 802.3u 100Base-Tx Ethernet
 IEEE 802.3af Power over Ethernet

2.2. NETWORK CABLE

Network cable 10BASE-T: 2-pair UTP/STP Cat.3, 4, 5
 cable EIA/TIA-568 100-ohm (100m)
 100BASE-TX: 2-pair UTP/STP Cat.5 cable EIA/TIA-568 100-ohm (100m)

2.3. RF SPECIFICATIONS

Input 1-16

Connector: F-type 75 ohm, AC coupled

4-65 MHz :
 insertion loss: 1.5dB ± 0.2 dB
 Combiner mode -15 dB ± 1 dB
 Return loss: >20dB
 Isolation: >80 dB

4-1000 MHz :
 insertion loss: 4MHz: 1.5 dB, 1000MHz: 2.5 dB
 Frequency ripple: < 0.5 dB
 Return loss: >18dB
 Isolation: >60 dB

Output:

Connector: F-type 75 ohm, AC coupled

	Kronback ApS Lautrupvang 15 DK-2750 Ballerup Denmark Web: www.kronback.com Fax:(+45) 46 907 910		Page 12 of 33
--	--	--	---------------

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

2.4. CONSOLE

Connector: RJ 45
RS232 standard
Communication parameters:
9600 baud
8 data bits
1 stop bit
No parity
No flow control

2.5. CERTIFICATION

CE
FCC

2.6. PHYSICAL SPECIFICATIONS

Height 43.8 mm (1 unit)
Width 482 mm (standard 19" dimensions)
Depth 55mm (2.2")
Weight 850 g (1.9 lb)

2.7. ELECTRICAL

Power over Ethernet according to IEEE803.2af
IEEE803.2af CLASS I device (<4W)
Reverse polarity protection
Power consumption 2 Watt

2.8. ENVIRONMENTAL

Operating Temperature: 5°C ~ 45°C [41°F ~ 113°F]
Storage Temperature: -20°C ~ 55°C [41°F ~ 113°F]
Operating Humidity: 10% ~ 90%, non-condensing
Fan-less device

	Kronback ApS Lautrupvang 15 DK-2750 Ballerup Denmark Web: www.kronback.com Fax:(+45) 46 907 910		Page 13 of 33
--	--	--	---------------

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

3. User interface

3.1. RF SWITCH menu



From the **RF SWITCH** menu inputs can be assigned to the **S16** output.

3.1.1. Active Input

The Active input displays the current active input.

3.1.2. Input Selection

Dependant on the MASTER/SLAVE configuration in the **SETUP** menu 16 up to 256 input selections can be chosen from.


3.1.3. Submit input selection button

When the desired input has been selected, press "*Submit Input Selection*" to commit the selection.

	Kronback ApS Lautrupvang 15 DK-2750 Ballerup Denmark Web: www.kronback.com Fax:(+45) 46 907 910		Page 14 of 33
--	--	--	---------------

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

3.2. INPUT menu



Dynamic Menu

The **INPUT** menu is used to enter descriptive names for each input.

The menu is dynamic, providing all **S16** that is working together in MASTER/SLAVE setup to be named from the MASTER **S16**.

The top bar displays the **S16** units that can be named.

In this example 3 SLAVES and 1 MASTER can have names assigned.

→ Note:

The MASTER input page section has only 13 inputs as three inputs are used for the cascade of the 3 SLAVES.

Descriptive name fields.

The names in the descriptive name fields can be entered up to 28 characters long, and can contain standard ASCII characters as well as domestic characters


Save system configuration button

To store the input names in the **S16** flash memory press the *Save System Configuration* button.

	Kronback ApS Lautrupvang 15 DK-2750 Ballerup Denmark Web: www.kronback.com Fax: (+45) 46 907 910		Page 15 of 33
--	---	--	---------------

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

3.3. SUPPORT menu



The **SUPPORT** menu contains technical information, hardware and firmware versions and IP parameter information.

3.4. CONTACT menu




Contact details for Kronback Tracers support can be found in the **CONTACT** menu.

	Kronback ApS Lautrupvang 15 DK-2750 Ballerup Denmark Web: www.kronback.com Fax:(+45) 46 907 910		Page 16 of 33
--	--	--	---------------

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

3.5. SETUP menu



The **SETUP** menu is used to define the topology when multiple external switches are connected as SLAVES to the MASTER **S16** for input expansion.

3.5.1. IP address

IP address of the connected switches. These must be formatted as IP-addresses (e.g. 192.168.205.101) DNS names are not allowed.

3.5.2. Port

The port number used for the IP socket connection to the external switches. These are factory preset to 1000 in the **S16** switches, but can be changed from the console interface of the **S16**.

	Kronback ApS Lautrupvang 15 DK-2750 Ballerup Denmark Web: www.kronback.com Fax:(+45) 46 907 910		Page 17 of 33
--	--	--	---------------

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

3.5.3. Switch topology

Up to 16 external switches can be defined, providing a 256 input **S16** MASTER/SLAVE system.

The number of inputs that is set via the **SETUP** menu is globally changing all pages and menus in the **S16** related to inputs.

3.5.4. Input steps

Each additional input switch provides 16 extra inputs, but occupies 1 input for the cascade connection to MASTER **S16**, consequently the input increments are in steps of 15.

Number of SLAVE switches	Number of inputs
MASTER alone	16
1	31
2	46
3	61
4	76
5	91
6	106
7	121
8	136
9	151
10	166
11	181
12	196
13	211
14	226
15	241
16	256

External switches must be connected to the MASTER **S16** from input 16 and down. The inputs of the **S16** that are not used for the cascading are always the last inputs of the system.

Please see the "Topology example 61 inputs" chapter.


	Kronback ApS Lautrupvang 15 DK-2750 Ballerup Denmark Web: www.kronback.com Fax:(+45) 46 907 910		Page 18 of 33
--	--	--	---------------

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

3.5.5. Topology example 61 inputs

A 61 input system is built of 1 **MASTER S16** and 3 **SLAVE S16**.

- **SLAVE 1** is connected to the **MASTER's** input 16. (input 1 to 16)
- **SLAVE 2** is connected to the **MASTER's** input 15. (input 17 to 32)
- **SLAVE 3** is connected to the **MASTER's** input 14. (input 33 to 48)
- This leaves input 1 to 13 of the **MASTER** free (input 49 to 61)



kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

3.5.6. State check

The state of each SLAVE and the MASTER setting can be verified by viewing the LED´s over each f-connector.

To verify correct configuration, simply run through all inputs from the **SWITCH** menu. Check that the correct LED´s on the SLAVE and MASTER fronts are lighting.

For further assurance, a signal generator could be connected to each input for verification of correct signal paths and levels.

3.5.7. LED´s on unused inputs


Note that the MASTER does not switch the LED´s on inactive SLAVE switches off. The reason for this is to avoid unnecessary IP traffic on switch-off commands and to ensure optimal switching speed. However the combination of the MASTER LED and the LED of the associated SLAVE switch will still be correct.

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010


4. SP16T and Combiner mode

The **S16** has 2 main operation modes. It can run as a SP16T switch with 16 inputs where only one input is assigned to the **S16** output. The Web based GUI supports only the SP16T mode. The socket command interface supports control of both modes.

4.1. SP16T mode



4.2. Combiner mode



kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

5. Network Setup

5.1.1. Factory network settings

The **S16** is shipped with following factory settings:

Setting	Value
IP Address	192.168.205.80
Subnet Mask	255.255.255.0
Gateway	192.168.205.1
TCP Socket port	1000

5.1.2. DHCP

The **S16** does not support DHCP, only fixed IP is possible.

5.1.3. Link speed

The **S16** supports auto negotiation and accepts the following link speeds and configurations:

Value
10 Mbit Half Duplex
10 Mbit Full Duplex
100 Mbit Half Duplex
100 Mbit Full Duplex

Forced link speed is not supported.

5.1.4. Network configuration.

The Network parameters are configured via the Console interface.

See the chapter **Console interface** for more information on setting network parameters.

	Kronback ApS Lautrupvang 15 DK-2750 Ballerup Denmark Web: www.kronback.com Fax: (+45) 46 907 910		Page 22 of 33
--	---	--	---------------

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

6. Console interface

The console interface is activated during power-up of **S16**.
During **S16** operation the console interface provides status and debug information

```

*****
*           S16 SWITCH           *
*****
S16 compiled Dec  4 2008 10:31:04
Slavecount 0
Load portnames at Page 3 and 4

Press any key to enter setup
In 5
In 4
In 3

```

The **S16** is configured from the front panel using the RS232 connector marked **CONSOLE**.

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

6.1.1. RS232 parameters

RS232 parameter	Value
Baud rate	9600 bps
Data bits	8
Parity	None
Stop bit	1
Flow control	None

6.1.2. Console Cable

The Console interface is accessed using a Kronback tracers blue console cable marked "*Kronback Tracers x16 console cable*"

The pinout of kronback tracers x16 console cable is:

S16 RJ45 pin	direction	PC RS232 dsub9 female	Function
3	→	2	S16 data TX
4		5	ground
5		5	ground
6	←	3	S16 data RX
7		5	ground
8		5	ground

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

6.1.3. Using the console interface

Few seconds after **S16** has been powered, the Console interface responds with the following message:

```

*****
*           S16 SWITCH           *
*****
S16 compiled Dec  4 2008 10:31:04
Slavecount 0
Load portnames at Page 3 and 4

Press any key to enter setup
In 5
In 4
In 3

```

Press a key during the countdown from 5 to 1. The console interface enters the configuration menu:

6.1.4. Configuration menu

```

*****
*           LAN SWITCH           *
*****
* 1) Set IP address             *
* 2) Set Port                   *
* 3) Factory Reset              *
* 4) Exit                       *
*****
* Please select an option      *

```

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

6.1.5. Command 1, Set IP address

The **S16** is shipped with the following factory settings:

Setting	Value
IP Address	192.168.205.80
Subnet Mask	255.255.255.0
Gateway	192.168.205.1

To change the IP address press 1 in the configuration menu. The current IP settings are displayed:

```

*****
* Please select an option *
*****
*           IP setting           *
*****
* IP:      192.168.205.080      *
* SUBNET:  255.255.255.000    *
* GATEWAY: 192.168.205.001    *
*****
* Do You wish to change[Y/N] *

```

Press Y to change the settings for IP address, Subnet mask and Gateway:

```

*****
* IP:      192.168.205.081      *
* SUBNET:  255.255.255.000    *
* GATEWAY: 192.168.205.001    *
*****
* Do You wish to change[Y/N] *
* Enter IP  xxx.xxx.xxx.xxx:  *
192.168.205.81
* Enter SUBNET xxx.xxx.xxx.xxx: *
255.255.255.0
* Enter GATEWAY xxx.xxx.xxx.xxx: *
192.168.205.1_

```

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

6.1.6. Command 2, Set TCP port

The **S16** is shipped with following factory settings

Setting	Value
TCP port	1000

To change the TCP Port of the Socket remote control interface press 2 in the configuration menu. The current TCP Port is displayed:

```

*****
*          PORT setting          *
*****
* PORT:      01000              *
*****
* Do you wish to change [Y/N]   *

```

Press Y to change the settings for IP TCP Port:

```

*****
*          PORT setting          *
*****
* PORT:      01000              *
*****
* Do you wish to change [Y/N]   *
* Enter Port 0-65536            *
1001_

```

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

6.1.7. Command 3, Factory Reset

The factory reset brings the **S16** back to the shipped configuration:

- Clears all Descriptive text in the **INPUT** menu
- Clears all MASTER/SLAVE information in the **SETUP** menu
- Defaults the TCP Port to

Setting	Value
TCP port	1000

- Defaults the IP configuration to

Setting	Value
IP Address	192.168.205.80
Subnet Mask	255.255.255.0
Gateway	192.168.205.1

To perform a Factory Reset, press 3 in the configuration menu. This message is displayed:

```

*****
*      Factory Reset      *
*****
* This will erase all    *
* configuration to      *
* factory settings     *
* Do You wish to reset[Y/N] *

```

Press Y to commit the Factory Reset

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

6.1.8. Command 4, Exit

To exit the console configuration interface and start the **S16**, pres 4 in the configuration menu.

The console interface exits with this message:

```
Continue
MAC address.....: 00-1F-59-16-0E-3A
IP address.....: 192.168.205.81
Subnet mask.....: 255.255.255.0
Default gateway: 192.168.205.1
```

the **S16** is now operational.

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

7. Socket command protocol

The socket command protocol is a binary protocol used for remote control of the **S16**.

The protocol can be used to remote control the **S16** from a remote command computer over Ethernet. The remote computer must initiate the socket connection.

In MASTER/SLAVE mode the **S16** MASTER is using the socket protocol to control the **S16** SLAVES.

In case of no activity in 30 seconds **S16** is disconnecting, and a new socket connection has to be established from the remote computer.

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

7.1. SET OUT

The SET OUT 1 command assigns any input of the **S16**, including ALL-OFF to the Output.

This command is compatible with the Kronback Tracers 16·4, 16x4 RF matrix switch "SET OUT1".

Format:

command	Data [BYTE]	suffix
0x01	0x00 : ALL-OFF 0x01: input 1 ... 0x10: input 16	0xFF

Reply:

command	Data [BYTE]	suffix
0x02	0x00 : ALL-OFF 0x01: input 1 ... 0x10: input 16	0xFF

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

7.2. GET OUT

The GET OUT reads current input assigning status of the **S16** Output, including ALL-OFF
This command is compatible with the Kronback Tracers 16·4, 16x4 RF matrix switch
"GET OUT1".

Format:

command	suffix
0x02	0xFF

Reply:

command	Data [BYTE]	suffix
0x02	0x00 : ALL-OFF	0xFF
	0x01: input 1	
	...	
	0x10: input 16	

kronback tracers	Status:	Version:
	Final	1.0
Titel : Configuration and Operation manual, kronback tracers S16		15/01/2010

7.3. SET Combiner mode

The following command is used to activate the **S16** combiner mode:

command	Data [BYTE1]	Data [BYTE2]	suffix
0x01 0x11	Binary representation of input 9 to 16	Binary representation of input 1 to 8	0xFF

Reply:

command	Data [BYTE]	suffix
0x02	0x00	0xFF

The combiner command is accumulative. New cross points adds to existing. To rewrite a clear command must be sent:

command	Data [BYTE]	suffix
0x01	0x00 : ALL-OFF	0xFF